

<ul> <li>SimpleSync</li> <li>Direct Command</li> <li>Clock Sync (NTP)</li> <li>Delay: 1 sec 2</li> </ul>	1.3 User Guide			
Name Right Screen Left Screen	▲ Probably Pia Teo Kie Kono Naj All Dial Dial Control (Section 200) All Dial Dial Dial Control (Section 200) All Dial Dial Dial Dial Dial Dial Dial Di			
Take (return) Goto 10 Goto 20 Goto 30 End All (esc)				
SimpleSync connects with PlaybackPro Plus to provide multi-sys- tem, synchronized media playback.				

Cime n la Cure

# About SimpleSync

SimpleSync is a free companion application for PlaybackPro Plus and is designed as a multisync roll software tool. While many clients use it as a Primary and Backup control it was not designed to function in that manner.

SimpleSync acts as a command server, while instances of PlaybackPro Plus act as clients. It utilizes Apple's Bonjour technologies for easy discovery and communication over Ethernet networks.

On macOS up to version 10.12 (Sierra), the built in NTP (Network Time Protocol) can be used to minimize clock drift for accurate sync rolls.

## How do I get it?

Download SimpleSync from <u>www.dtvideolabs.com/download</u>. It does not require a license.

# **Table of Contents**

1 Before You Begin	3
11) PreFlight Checklist	3
2 Setup	3
21) General Hardware Setup	3
22 Configure macOS Networking	4
③ Interface	5
Configure SimpleSync	5
4.1 Command Options	6
42 NTP (Network Time Control) Setup	6
<b>5</b> Configure PlaybackPro Plus for SimpleSync	8
51) Select Listening Mode	8
52 SimpleSync Listening Options	8
6 SimpleSync FAQ	9




# 1.1 PreFlight Checklist

Each version of macOS has specific settings which have a great impact on playback performance. Before you begin, please visit <u>www.dtvideolabs.com/preflight</u> and configure each of your PlaybackPro Plus systems.



2 <u>Setup</u>

# 1 General Hardware Setup



Setup



All network settings should be made without SimpleSync or PlaybackPro Plus running.

## All other network ports such as Airport (wireless) must be turned off.

Computers should be networked with a gigabit ethernet switch (not a hub). If you are connecting only two systems you can use a direct wired connection between the two systems.

Open System Preferences > Network and configure using the fixed IP values below.



SimpleSync/Server IP Values	192.168.1.100	
PlaybackPro Plus/Client IP Vaues	192.168.1.101 through 192.168.1.200	
Subnet Mask for all systems	255.255.255.0	

Confirm PlaybackPro and SimpleSync network connections are not being blocked by the macOS Firewall. To review or change Firewall settings open System Preferences and then Security & Privacy. Click on the Firewall tab and then the Firewall Options button.





- (1) **Command Options** Determines how PlaybackPro Plus clients are cued
- (2) Delay Controls the delay between the time the "Take" button is clicked and playback begins. This helps ensure proper cueing of clips on all PlaybackPro Plus clients. The delay may be increased if there are a large number of computers. Delay is only available for Clock Sync.
- (3) Entering Clip Numbers Clips can be loaded into Preview on PlaybackPro Plus clients by typing their clip numbers directly on the keyboard. They will appear briefly in the interface window. Clip numbers can be assigned to the same, or to different clips, on each computer. This makes sync roll recall easy. They must match the numbers entered in the # fields of PlaybackPro Plus clients. To prevent your keyboard from producing unwanted alerts, go to System Preferences > Sound > Sound Effects and disable "Play user interface sound effects."
- (4) **Client List** A list of connected PlaybackPro Plus clients



(5) **Show Controls** - These controls affect Take, End All and Goto 10/20/30




There are 3 steps to properly configure SimpleSync:

- (1) Select the desired Command option
- (2) Optionally, configure NTP (Network Time Control) server and clients
- (3) Configure PlaybackPro Plus for SimpleSync



### **Direct Command**

Using Direct Command is quick and easy, but should only be used when absolute synchronization isn't necessary.



When Direct Command is used,

PlaybackPro Plus clients are triggered in nearly instantaneous succession. There may be a small latency between triggering the first computer and the last one, especially when a large number of computers are used. There is no clock sync with this option.

If you are using Direct Command you can skip the next section on NTP Setup.

### Clock Sync (NTP)

PlaybackPro Plus utilizes QuickTime for video decoding, which is based on each computer's real time internal clock. Clock Sync assures all client computer clocks are in perfect sync. Each computer is assigned a time in the very near future to begin playback so that successive frames will display at the expected time. If clips on different computers are started at exactly the same time, they will remain in sync as long as their internal clocks do not drift apart during the duration of the clip. Drift can occur when looping clips. Be sure to test content when looping clips.

## 4.2 NTP (Network Time Control) Setup

NTP is built into macOS up to version 10.12 (Sierra). It typically acts as a client of an Apple time server, but can point to a time server on a local network.

#### **NTP Server Setup**

One of your systems must be setup as the NTP server. This can be the system running SimpleSync or any of the other systems on the network. The system you have designated as the NTP time server will need to pull its clock information from the Apple time server "time.apple.com" so it will initially need to be connected to the internet but should be disconnected after all systems have syncronized their clocks. Connecting to the Apple time server is the default for all Mac systems.




#### www.dtvideolabs.com technical@dtvideolabs.com

## SimpleSync 1.3



### NTP Client Setup

On all playback systems, go to System Preferences > Date & Time and enter the IP address of the SimpleSync server (should be 192.168.1.100) in the "Set date and time automatically" field.



## **Clock Settings for Server and Client playback machines**

Go to the Clock tab on all playback machines and check "Display the time with seconds". This needs to be done without PlaybackPro Plus or SimpleSync running. Each machine should now have the time of the first machine.

••• <>	Date & Time	Q Search
	Date & Time Time Zone Clock	
🗹 Show date and	time in menu bar	
Time option	✓ Display the time with seconds	
	Use a 24-hour clock	
	Show AM/PM	
Date options:	Show the day of the week Show date	
Announce the t	ime: On the hour C Customize	e Voice
Click the lock to prevent fu	rther chances.	2
		1

## Troubleshooting NTP


A simple way to determine if the clocks are synchronized is to:

- (1) Uncheck the "Set Date and Time Automatically" checkbox
- (2) Set the time ahead 1 hour
- (3) Save the time
- (4) Enable the "Set Date and Time Automatically" checkbox

The time should reset to the time on the server.

Configure PlaybackPro Plus for SimpleSync

To activate SimpleSync functionality within PlaybackPro Plus, select "Network Setup" in the upper right corner of the of the PlaybackPro Plus window. SimpleSync must be running on one of the systems on the network for this option to be available.



**Not Connected** 

 No Control UDP Listen

**TCP/IP Listen** 

Simple Sync

Done

Connection:

If the SimpleSync option isn't visible, there is a problem with your network setup.

# 5.1 Select Listening Mode

PlaybackPro Plus offers several remote control options. Because SimpleSync is the focus of these instructions, select it from the list.

- (1) **No Control** Stops all listening for remote commands
- (2) **UDP Listen** System listens for commands over ethernet from remote system
- (3) **TCP/IP Listen** System listens for commands over ethernet from remote system
- (4) **SimpleSync** System listens for commands from SimpleSync

# 5.2 SimpleSync Listening Options

**Name** - Use this to name the system for reference within the SimpleSync interface

**Delay** - This setting allows you to create a delay for an individual system clock when using the NTP option.

Simple Sync						
Connection:		Simple Sync			\$	
Name	Right Screen					
Delay	0.00	00000	Seconds	;		
_				Done		

SimpleSync FAQ

## Does SimpleSync have to run on all systems?

Only one instance of SimpleSync should be running. The recommended configuration is for it to run on a separate system from the PlaybackPro Plus systems but it is possible to run it on a system that is also running PlaybackPro Plus.

## Can I run SimpleSync on systems with different versions of macOS?

All systems should be running the same version of macOS and the same version of PlaybackPro Plus. You can use any combination of PlaybackPro Plus Internet Activated and USB licenses.

Do I have to have numbers in the # field for SimpleSync to work?

All PlaybackPro Plus playlists must have alphanumeric characters in the # (clip number) field.

How do I get it?

Download SimpleSync from from <u>www.dtvideolabs.com/downloads</u>. It does not require a license.